



## **Bike box lock replacement**

Please take a look at the attached photo's re the fitting of the replacement lock.

The fitting of the new one is quite simple, just follow the instructions below and take a look at the images attached. Do this with the lock in the closed position.

Image 1 - You firstly need to insert the end of the lock with the long lip (A) in to the hole, in Image 2 you will see a the gap (circled in red) that will allow you to fully slot the lock in to place but first, position the lock in the hole as in Image 3.

Now as in image 4, push the lock towards the centre of the case in the direction of the arrow. This is where the gap in image 2 gives you the clearance at end "B" for the lock to slot fully in to the hole, allowing the small screw in the end of the lock to slip past the edge of the hole.

Once this is done, pull the lock slightly towards the outer edge of the case and this should line up the screw hole in the lock at end "A" with the hole in the aluminium frame of the case. Insert the screw, attach the nut, tighten up and you are done.

Many thanks,

Richard

